

## Cleaning & Caring For Your Anodized Aluminum

Anodized aluminum is easy to clean – just flush the surface with warm water and soap using moderate pressure.

In the event that the material still doesn't look clean, try using a soft brush or sponge with warm water.

If after completing the previous steps you still have visual dirt – try a mild detergent like the ones listed below, along with a soft brush or sponge and fresh warm water. Clean first in a horizontal motion, and then with a vertical motion.

Rinse thoroughly with warm water.

## Recommended Cleaning Agents

- 10% Ammonium
- Mineral Spirits
- Organic Cleaners
- Acetone
- Methanol
- PH-Neutral Solvents
- MEK

## Keep Your Warranty Fresh

Maintaining your anodized aluminum is an important component to maintaining your twenty-year limited warranty. Document each time you clean your anodized aluminum. (Required at least annually.)

All of us at Lorin Industries, Inc. are dedicated to providing our customers the best possible value in anodized aluminum solutions. We know that you have choices, and we remain committed to making Lorin Industries, Inc. your choice for your anodized aluminum needs.

Steven F. Soderberg
Corporate Marketing Manager –
Lorin Industries, Inc. (231) 727-6650
stevensoderberg@lorin.com